

FIG. 1




FIG. 2




FIG. 4




FIG. 5

REQUEST ID	INPUT SOURCE ID	PARAMETER
------------	--------------------	-----------

INPUT SOURCE ID : PANEL = 00、REMOTE CONTROLLER = 01、
CAMERA = 03

0964008-052301

FIG. 6

USER INPUT	REQUEST ID	PARAMETER	REQUEST INTERPRETATION	COMMAND ID	COMMAND INTERPRETATION
CAPTURE BUTTON DOWN	01	01	NONE	01	START IMAGE CAPTURE
CAPTURE BUTTON UP	01	02	NONE	NONE	NONE
ZOOM TELE BUTTON DOWN	02	01	START ZOOMING IN TELE-PHOTO DIRECTION	02	START ZOOMING IN TELE-PHOTO DIRECTION
ZOOM TELE BUTTON UP	02	02	STOP ZOOMING	04	STOP ZOOMING
ZOOM WIDE BUTTON DOWN	03	01	START ZOOMING IN WIDE DIRECTION	03	START ZOOMING IN WIDE DIRECTION
ZOOM WIDE BUTTON UP	03	02	STOP ZOOMING	04	STOP ZOOMING
FLIP BUTTON DOWN	04	01	FLIP IMAGE VERTICALLY	05	FLIP IMAGE VERTICALLY
FLIP BUTTON UP	04	02	NONE	NONE	NONE

FIG. 7

REQUEST ID	REQUEST ROUTE
01	01(SEND TO HOST PC)
02	00(INTERNAL INTERPRETATION/EXECUTION)
03	00(INTERNAL INTERPRETATION/EXECUTION)
04	00(INTERNAL INTERPRETATION/EXECUTION)
05	01(SEND TO HOST PC)

09864008 052301
105250" 80049860

FIG. 8




FIG. 9




FIG. 10




FIG. 11

